



NOTICE

Royal Rapide Cockpit - Tarmac SL7 transition spacer

SERVICE PART NUMBER:

	DESCRIPTION
S232500001	SL7 to Rapide transition spacer

SUMMARY:

When installing the Royal Rapide Cockpit onto the Tarmac SL7 there is a gap between the upper transition spacer and the curvature of the cockpit. A transition spacer is available which follows the curvature of the cockpit and closes the gap, service part number S232500001.

LANGUAGE VERSIONS

- EN: Click **HERE** to download this document in your language
- CNS: **单击此处以您的语言下载此文档。**
- CNT: **單擊此處以您的語言下載此文檔。**
- CZ: Kliknutím **SEM** stáhnete tento dokument ve svém jazyce.
- DA: Klik **HER** for at downloade dette dokument på dit sprog.
- DE: Klicken Sie **HIER**, um dieses Dokument in Ihrer Sprache herunterzuladen.
- ES: Haga clic **AQUÍ** para descargar este documento en su idioma.
- FI: Napsauta **TÄSTÄ** ladataksesi tämän asiakirjan omalla kielelläsi.
- FR: Cliquez **ICI** pour télécharger ce document dans votre langue.
- HR: Kliknite **OVDJE** za preuzimanje ovog dokumenta na vašem jeziku.
- IT: Clicca **QUI** per scaricare questo documento nella tua lingua.
- KR: 귀하의 언어로 된 이 문서를 다운로드하려면 **여기**를 클릭하십시오.
- NL: Klik **HIER** om dit document in uw taal te downloaden.
- NO: Klikk **HER** for å laste ned dette dokumentet på ditt språk.
- PL: Kliknij **TUTAJ**, aby pobrać ten dokument w swoim języku.
- PT: Clique **AQUI** para baixar este documento em seu idioma.
- RU: Нажмите **ЗДЕСЬ**, чтобы скачать этот документ на вашем языке.
- SK: Kliknutím **SEM** stiahnete tento dokument vo svojom jazyku.
- SL: Kliknite **TUKAJ** za prenos tega dokumenta v vašem jeziku.
- SV: Klicka **HÄR** för att ladda ner det här dokumentet på ditt språk.